






How to exchange the brush roller



2



3 **brush roller:**
BRZ1AB



4

