

# General safety warning signs and instructions



**WARNING**

General warnings, please observe the following instructions!



Warning, crushing hazard!



Warning, sharp object!



Warning of hot surfaces!



Warning of flammable substances / fire hazard warning



Read the operating instructions for your device and the enclosed safety instructions carefully!



Always disconnect your device from the power source before carrying out repair work!



Always wear suitable protective gloves!

# Safety instructions

## Iron

### IMPORTANT

**These are only exemplary illustrations, please always refer to the operating instructions for your device!**

All safety instructions describe in detail the potential risks they address and contain precise instructions on how to avoid injury, damage to property or electric shock as a result of improper handling. Please observe the following guidelines:



### WARNING



1. Disconnect the appliance from the power supply before carrying out the procedures described.
2. Use protective gloves before starting work.
3. Only carry out the described procedures when the appliance is cold.

- Always disconnect the appliance from the power source before carrying out installation work.
- Installation and repairs should be carried out by qualified specialists in accordance with the manufacturer's instructions and the applicable local safety regulations. Therefore, only carry out repairs or replace parts yourself if this is expressly provided for in the user manual.
- Only use certified spare parts, in case of doubt original spare parts.
- Children must be supervised to ensure that they do not play with accessories or spare parts.
- Do not touch accessories and spare parts with wet hands.
- Danger from hot surfaces: Never touch the hot soleplate as it can cause burns. Keep children away and prevent them from using the appliance as a toy.
- Risk of burns: Avoid contact during and immediately after use. Allow the appliance to cool down completely before bringing cloths or other flammable materials near it.
- Caution when steam escapes: Keep hands and body parts away from the steam outlet as the hot steam can cause burns.
- Suitable work gloves should always be worn when installing, maintaining or fitting spare parts.
- Children and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge should only use the appliance under supervision or after thorough instruction by a responsible person
- Keep packaging material out of the reach of children: Children could wrap themselves in packaging materials such as plastic bags or foil or pull them over their heads, which could lead to suffocation. Therefore, make sure that packaging materials are kept out of the reach of children.

## Mounting iron

